

ASSEMBLY INSTRUCTIONS:

FIGURE 1.

1. Carefully unpack all parts from carton referring to FIGURE 1 for parts identification.
2. Place the BASE on level surface and locate the BUTTERFLY SHADE. Pass the SOCKET HOLE at the bottom of the BUTTERFLY SHADE over the SOCKET.
3. Locate the THUMB SCREW and pass through MOUNTING HOLE, threading into the BASE. Hand tighten until snug.
4. Locate the CANDLE COVER and place over the SOCKET.
5. Install BULB (supplied) referring to fixture markings and / or labels for maximum wattage.
6. Situate completed lamp where desired and plug SUPPLY CORD into wall mounted receptacle.

