## **SYMMONS**<sup>®</sup> Showeroff<sup>®</sup>

Automatic Shower limiting Installation and Service

## **Timing Instructions:**

- 1) Loosen Allen set screw (NS-28) on side of knob (NS-3).
- 2) Pop-out plug-button (NS-29) with sharp pointed tool.
- 3) Insert thin blade screw driver in center hole of knob (NS-3) and into the slot of the push-rod (NS-4).
- 4) Turn knob (NS-3) clockwise while holding screw driver firmly. Turn until push-rod (NS-4) is 3/16" from top of knob (NS-3). This will give minimum time cylce. Replace plug-button (NS-29)
- 5) Tighten Allen set screw (NS-28). To increase time cycle, turn knob (NS-3) counter-clockwise in step 4.

## Valve

For California Residents WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

## Service:

NS-13R - Washer & Gasket Repair Kit , includes piston unit, control rod sleeve, sleeve, retainer and all necessary washers and gaskets.

NS-1 - Complete Replacement Unit, includes the complete working unit of the valve assembled and tested)

New installations, before turning on the water supply, remove cartridge, open stop and thoroughly flush supply line. Replace cartridge and turn on supply. If supply is not thoroughly flushed of dirt and foreign matter, the valve will not shut off.

Long idle periods - If the valve has a long idle period between installation and use, or is used seasonally, disassemble the cartridge unit and lightly lubricate all moving parts.



