

UTTERMOST

ASSEMBLY INSTRUCTIONS

21346

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF WHILE POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

We suggest a licensed professional electrician for installation

Installation Steps

1. Turn power off at fuse or circuit box before starting installation process.
2. Carefully unpack your new fixture and lay out all the parts on a clear surface.
3. Choose the suitable number of stems and install the Stem-1, Stem-2 into the Tube.
4. Please loose the Hex nut and disassemble Swivels.
5. Thread the Swivels into the Stem-1.
6. Insert the nipples of Swivels into holes in Canopy, then place the Iron plate, the Support cable, the lock washers over the nipples, then secure with the Hex nuts.
7. Thread the Mounting screws into the matching holes of the Circular strap, and tighten with the Small hex nut. Thread the Ground screw into the hole of the Circular strap. Secure the Circular strap to the outlet box with the Outlet box screws.
8. Attach the Hooks on the end of the Support cables to the Circular strap.
9. Make Wire connections with Wire Connector:
 - The smooth wire (w/ marking) from fixture to Black Wire from power source.
 - The ribbed wire (w/o marking) from Fixture to White Wire from power source.
 - Attach the Ground Wire and house ground wire to the Mounting bar with the green Ground screw.Carefully tuck wires back into the Outlet Box.
10. Place the fixture Canopy over the two Mounting screws so they protrude through the holes in the Canopy. Thread the Ball nut onto the Mounting screws and continue turning until the fixture is snug against the ceiling.
11. Slide the Glass shades over the Sockets, then secure with the Socket rings.
12. Install the light bulbs (Not Supplied) in accordance with the fixture's specifications.

DO NOT EXCEED THE MAXIMUM WATTAGE RATING!

