



UTTERMOST


Assembly instruction

STYLE:23125

Parts List

A	chair Top	1PC
B	Leg	4PCS
C	Flat Washer	8PCS
D	Spring Washer	8PCS
E	Bolt	8PCS
F	Allen Wrench	1PC

1. Lay the chair top (A) on a solid non-abrasive surface such as carpet or cloth as shown below.
2. Attach each Leg (B) to the seat frame of chair top (A) as shown. using (C/D/E) securely tighten all bolts by Allen wrench (F).



3. Please cover (H) Fabric.

4. Assembly is now complete.

