



UTTERMOST


Assembly Instruction

ITEM NO.:24302

Parts list

a	table top	1pc
b	legs	2pcs
c	Connecting	2pcs

d	bolt	12pcs
e	washer	12pcs
f	lock washer	12pcs
g	wrench	1pc



1. Take the parts carefully out of carton, and then place them on a flat and soft surface, making sure that parts will not be damaged.

2. Place the table top (a) lay on a flat and soft surface, then assembly (b) (c) with table top (a) from the hole and tenon.

3. Use the wrench (g) to tighten up by bolt (d) and washer (e), lock washer (f).

4. Stand the table and the assembly is complete.

To Clean, wipe with soft dry cloth.