


### **Ashville Chat Set**

Item#: 63742





# ATTACH YOUR RECEIPT HERE

Keep a copy of your proof of purchase or order confirmation which will be needed if you need to contact us about warranty coverage.

Purchase Date:





### Questions, problems, missing parts?

Before returning to your retailer, our Florida-based customer service team is available:

Call toll-free (866) 985-7877 9 a.m. – 9 p.m., EST

Email cservice@welltraveled.net

Live chat www.balkenehome.com 9 a.m. – 6 p.m., EST, Monday – Friday

03242021



#### **BEFORE YOU BEGIN**

Before beginning assembly, make sure all parts are present. Compare parts received with the parts list. If any part is missing or damaged, do NOT attempt to assemble the product. Please read and understand this entire manual before attempting to assemble, operate or install this product. If you have any questions regarding the product, please contact Customer Service.



#### GENERAL INFORMATION

Your new patio set is made from the finest materials available. It should provide years of enjoyment with minimal care.

Keep your patio set clean. For best results, clean with a soft, damp cloth. You may use a standard glass cleaning spray to clean the glass tabletop. If you use furniture covers, always make sure the patio set is clean and completely dry before covering, as mold may form in dark, wet places. Remove cushions prior to covering and store them in a dry, temperature controlled place. Check the hardware on your patio set regularly to make sure it is secure.

The weight limit is 220 lb/100kg per chair, 440 lb/200kg total for sofa.




#### SAFETY INFORMATION


#### WARNING

Do not stand or allow children to stand on the assembled product. Ensure hardware is securely in place. Perform periodic checks to make sure the connections are secure and adjust if needed. The glass tabletop is tempered for strength but may break or chip if dropped, struck sharply, or otherwise abused. Do not sit or stand on the glass tabletop, and take reasonable precautions to avoid injury in the event of glass breakage.

#### **CAUTION**


Read all instructions before beginning assembly. Failure to do so may result in faulty assembly and potential injury. Assemble the item on a soft, non-abrasive surface such as carpet or cardboard to avoid damaging the item.






PART	DESCRIPTION	<b>QUANTITY</b> (per chair)
A	Seat Panel	1
В	Backrest	1
G	Left Panel*	1
D	Right Panel*	1
<b>(3</b>	Seat Cushion	1

<sup>\*</sup>When facing the front of the chair













Washer Qty: 11



Hex Wrench

Assemble in a clear area on a spacious, nonabrasive surface such as a carpet or blanket. Wait to fully tighten hardware until final step. Do not over-tighten hardware.

Locate the Backrest (3) and Seat Panel (4). Place a Washer (6) on a Bolt (7). Align the panels as shown. Insert the Bolt with Washer through the eyelet in the underside of the Seat Panel and into the hole in the middle of the bottom of the Backrest.


Tighten using the Hex Wrench, but do not over-tighten.




#### Hardware Used:

**6** Bolt (M6x40) ×1

**⊘** Washer ×1



Attach the Left and Right Panels ( ) to the assembled seat: Place a Washer ( on each of 6 Bolts ( ). Align the eyelets on the Left Panel with the holes in the edge of the Seat Panel as shown, then insert a Bolt with Washer into each of the 3 aligned sets of eyelets (1 behind the front panel of the seat, 2 along the side of the seat). Gently tighten using Hex Wrench without fully tightening. Repeat to attach the Right Panel.





#### Hardware Used:

**6** Bolt (M6x40) ×6

**@** Washer ×6

Secure the Side Panels to the Backrest ③. Place a

Washer ⑤ on each of 4 Bolts ⑥. Insert a Bolt with


Washer through each of the 4 aligned sets of eyelets.



#### Hardware Used:

**6** Bolt (M6x40) x4


**@** Washer ×4




Turn assembled chair upright on a flat, level surface to ensure that it sits squarely and level on the ground. Adjust fastenings if needed, then firmly tighten all **Bolts** installed in Steps 1–3.


Place the **Seat Cushion** (3) in the seat.


Repeat Steps 1-4 to assemble second chair.




Your Ashville Chairs are fully assembled!











PART	DESCRIPTION	QUANTITY
A	Seat Panel	1
В	Backrest	1
G	Left Panel*	1
D	Right Panel*	1
<b>(3</b>	Seat Cushion	1

\*When facing the front of the sofa







### **HARDWARE CONTENTS**







Washer Qty: 12



Hex Wrench

Assemble in a clear area on a spacious, nonabrasive surface such as a carpet or blanket. Wait to fully tighten hardware until final step. Do not over-tighten hardware.

Locate the Backrest 3 and Seat Panel 4. Place a


Washer 5 on each of 2 Bolts 6. Align the panels as shown. Insert the Bolts with Washers through the eyelets in the underside of the Seat Panel and into the holes at the bottom of the front of the Backrest.

Tighten using the **Hex Wrench**, but do not over-tighten.



#### Hardware Used:

- @ Bolt (M6x40) x2
- Washer x2




Attach the Left and Right Panels ( ) to the assembled seat: Place a Washer ( on each of 6 Bolts ( ). Align the eyelets on the Left Panel with the holes in the edge of the Seat Panel as shown, then insert a Bolt with Washer into each of the 3 aligned sets of eyelets (1 behind the front panel of the seat, 2 along the side of the seat). Gently tighten using Hex Wrench without fully tightening. Repeat to attach the Right Panel.



#### Hardware Used:

- **6** Bolt (M6x40) ×6
- ♠ Washer x6




Secure the Side Panels to the Backrest ③. Place a Washer ① on each of 4 Bolts ③. Insert a Bolt with Washer through each of the 4 aligned sets of eyelets.



#### Hardware Used:

- **6** Bolt (M6x40) x4
- Washer ×4



### **ASSEMBLY: SOFA BENCH**


### BALKENE -HOME-


Place assembled sofa upright on a flat, level surface to ensure that it sits squarely and level on the ground.

Adjust fastenings if needed, then firmly tighten all **Bolts**.


Place the **Seat Cushion (3** in the seat.

Your Ashville Sofa is fully assembled!





PART	DESCRIPTION	QUANTITY
A	Table Frame	1
<b>B</b>	Shelf	1
0	Leg	4
D	Glass Tabletop	1





### HARDWARE CONTENTS







Washer Qty: 12



Hex Wrench

Assemble in a clear area on a spacious, nonabrasive surface such as a carpet or blanket. Wait to fully tighten hardware until final step. Do not over-tighten hardware.

# BALKENE

Place the Table Frame (B) upside-down on a protected surface (Bolt holes will be visible near each corner). Place a Washer () on each of 8 Bolts ().

Position a Leg at the corner of the Table Frame as shown, aligning the eyelets in the top plate of the Leg with the holes in the Table Frame. Insert a Bolt with Washer into each of the the aligned sets of eyelets.

Repeat to install remaining 3 Legs.

Tighten Bolts with the Hex Key, but do not over-tighten.



Hardware Used:

**G** Bolt (M6x20) ×8

**6** Washer ×8

**Note:** for illustration purposes, the table is shown upside-down, but this step may be easier to complete with the table on its side or upright. Place a Washer ( on each of 4 Bolts (3). Position the Shelf between the installed Legs resting against the lower brackets of each Leg, then insert a Bolt with Washer through each bracket eyelet and into the threaded holes in the bottom of the **Shelf** 


Tighten Bolts with the Hex Key, but do not over-tighten.



Hardware Used:


**9** Bolt (M6x20) ×4


**6** Washer ×4



Carefully place the Glass Tabletop ① on the assembled Table Frame.

Your Ashville Table is fully assembled!











#### LIMITED WARRANTY

Customers in the Contiguous US

With proof of purchase from an authorized retailer, this product is warranted for a period of 1 year from original purchase date against defects in materials and workmanship under normal use. This warranty does NOT cover normal wear/weathering, exposure to water, freezing temperatures, oils, fluids, or chemicals OR use in a commercial context if the unit is not designated as a commercial model. At Well Traveled Living's sole discretion, products under warranty will be repaired and/or replaced at no charge to the customer. Returns sent back to Well Traveled Living must be sent via prepaid freight in the original retail packaging.

For warranty service, contact Balkene Home/Well Traveled Living at the address, phone numbers or website and email listed in this owner's manual. Be sure to have your sales receipt, date of purchase and catalogue/model numbers available when calling. All warranty service will be coordinated by Well Traveled Living's Amelia Island, Florida service center. This warranty is extended only to the original owner. Proof of purchase will be required before warranty service is rendered. The sales receipt is the only valid proof of purchase. This warranty only covers failures due to defects in materials or workmanship which occur during normal use. Failures and/or damage which result from accident, negligence, misuse, abuse, neglect, mishandling, alteration or modification, failure to maintain, improper assembly or maintenance, service by unauthorized agency or use of unauthorized components or damage that is attributable to acts of God are NOT covered.

This limited warranty gives you specific legal rights and you may also have other rights which vary from jurisdiction to jurisdiction. The provisions of the United Nations Convention on Contracts for the Sales of Goods shall not apply to this limited warranty or the sale of products covered by this limited warranty.

- THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED.
- PURCHASER ASSUMES ALL RISKS IN THE ASSEMBLY AND OPERATION OF THIS UNIT.
- FAILURE TO FOLLOW WARNINGS AND OPERATIONAL INSTRUCTIONS CONTAINED IN THIS MANUAL CAN RESULT IN SEVERE PROPERTY DAMAGE AND/OR PERSONAL INJURY.
- · IN NO EVENT WILL WELL TRAVELED LIVING. OR ITS DIRECTORS, OFFICERS OR AGENTS BE LIABLE TO THE PURCHASER OR ANY THIRD PARTY. WHETHER IN CONTRACT, IN TORT, OR ON ANY OTHER BASIS, FOR ANY INDIRECT, SPECIAL, PUNITIVE, EXEMPLARY, CONSEQUENTIAL, OR INCIDENTAL LOSS, COST, OR DAMAGE ARISING OUT OF OR IN CONNECTION WITH THE SALE, MAINTENANCE, USE, OR INABILITY TO USE THE PRODUCT, EVEN IF WELL TRAVELED LIVING OR ITS DIRECTORS, OFFICERS OR AGENTS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH LOSSES. COSTS OR DAMAGES, OR IF SUCH LOSSES, COSTS, OR DAMAGES ARE FORESEEABLE. IN NO EVENT WILL WELL TRAVELED LIVING, OR ITS OFFICERS, DIRECTORS, OR AGENTS BE LIABLE FOR ANY DIRECT LOSSES, COSTS OR DAMAGES THAT EXCEED THE PURCHASE PRICE OF THE PRODUCT.
- · SOME JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO THE PURCHASER.

#### **EXTEND YOUR WARRANTY**

When you purchase a Fire Sense or Balkene Home product from any authorized retailer, you'll have peace of mind in knowing that it comes with a one-year warranty. Extend your warranty for *an additional year* when you review your item at **balkenehome.com** within 365 days of purchase.



### **Important Notice**

**Before returning to place of purchase** – for customer service and warranty issues:

Call toll-free (866) 985-7877 9 a.m. – 9 p.m., EST

Email cservice@welltraveled.net

Live chat www.balkehene.com 9 a.m. – 6 p.m., EST, Monday – Friday

Distributed by:

Well Traveled Living
716 S 8th Street, Amelia Island, FL 32034
balkenehome.com
cservice@welltraveled.net
(866) 985-7877