

**JRS**

Item No.	Part Description	Material	Repair Part No.			
			JRS5	JRS7	JRS10	JRS5LT
1	Drain plug ¼" NPT	Steel	6K2			
2	Vent plug ¼" NPT	Steel	6K1			
3	Elbow connector – tubing	Polypropylene	6K94			
4	Casing	Cast iron	1K342		1K382	
5	Gasket	N-8090	5K10			
6	Packing	BUNA	5K8			
7	Gland nut	Brass	4K12			
8	Nozzle	Delrin®	AN018			
9	Venturi tube	Lexan®	AD3330	AD3336	AD3339	AD3330
10	Separator plate seal ring	BUNA-N	5K6			
11	Separator plate	Polypropylene	5K253			
12	Diffuser (guidevane)	Lexan®	3K64	3K65	3K65	3K64
13	Impeller	Noryl®	2K4	2K60	2K61	2K4
14	O-ring	BUNA	5K230			
15	Mechanical seal – Rotary	Teepelite	10K2			
16	Mechanical seal – Stationary	Ceramic				
17	Seal housing	Amodel®	1K325			
18	Connector with locknut	Steel	6K24			
19	Pressure switch	NA	AS1			
20	Tubing – pressure switch	Polypropylene	6K92	6K101	6K108	6K92
21	Motor	Stainless steel shaft	SFJ04860	SFJ05860	SFJ06860	SFJ04860
22	Hex cap screw	Steel	13K80			
23	Grommet – base	BUNA	4K405			
24	Base – JRS5, JRS7, JRS10	Steel	4K399			4K449
	Tank base – JRS5LT (on tank model)					

