




ASSEMBLY INSTRUCTION: HLT2382



HARDWARE

- 1** Washer : 08 Pcs 
- 2** Nut : 08 Pcs 
- ADD Wrench : 01 Pc** 