



ASCENDING SLATE TABLETOP WATER FOUNTAIN WITH LED LIGHT GSI-868

Read assembly instructions carefully and follow the care instructions. Save these instructions for future reference.

Select a smooth, level surface to place the fountain. Assemble components on a soft, clean surface to avoid scratching or damaging the finish.



No.	PARTS	QTY.
A	Polished Stone Ball	1
B	Fountain Body	1
C	Finger Light	1
D	Electric Submersible Pump	1
E	Basin	1
F	Decorative Stones	1 PK



NOTE: The water tubing is built into the fountain body. Take care when handling the water tube; detaching the water tube from the fountain will damage the fountain and void the product warranty.

Adjust the flow control valve on the pump to halfway between maximum (+) and minimum (-) before first use; maximum flow rate may cause unwanted splashing.

ASSEMBLY

1. Connect Finger Light (C) to Pump (D).
2. Insert Finger Light (C) into the underside of Fountain Body (B).
3. Connect Pump (D) to the water tube on Fountain Body (B).
4. Gently place the assembled components onto Basin (E).
5. Place Polished Stone Ball (A) onto the fountain body.
6. Gently place Decorative Stones (F) onto the fountain body.
7. Fill the fountain with enough water to keep the pump fully submerged during operation; approximately 5 cups.
8. Firmly connect the AC Adapter and plug the power cord into a properly grounded GFCI outlet.

Note: When first used, there may be air trapped in the pump. It may take several minutes for the air to escape and water begins to flow.

⚠ IMPORTANT INFORMATION ⚠

USE & CARE

- FOR INDOOR USE ONLY.
- Keep fountain out of reach of children and pets.
- Keep power cord away from all heat sources. Do not place electrical cords in areas with high temperatures.
- Check the water level frequently to ensure the pump remains fully submerged; never allow the pump to run dry as it will burn out the motor.
- Only use water in this fountain; distilled water is recommended to prevent mineral buildup.
- Periodically change the water to reduce scale and buildup — clean components regularly for optimal performance and appearance.
DO NOT use harmful additives such as bleach, chlorine, etc.
DO NOT use abrasive materials to scrub the fountain.
- Always shut off the power supply before cleaning and maintaining the fountain and the recirculating pump.
- Take care when handling the pump; only pick it up by the body of the pump, never by the power cord.

TROUBLESHOOTING

- Ensure that the pump is fully submerged, add water if necessary.
- Check to make sure the power outlet is working; if in doubt about electrical connections, consult a certified electrician.
- Check the pump and tubing for obstructions.
- Check the flow control on the body of the pump as it may need to be adjusted to achieve the desired flow rate.
- If the light is not working, ensure the cable is fully connected and the seal is adequately tightened (do not over-tighten).
- If water is not flowing within several moments of the fountain being plugged in, unplug the power supply for a few moments and plug it back in; the pump may have air trapped inside it which can prevent water from circulating properly.

Any modification or failure to follow the recommended care will void the product warranty.