

**CAUTION:** Read instructions carefully and turn electricity off at main circuit breaker panel before beginning installation.


## 5642-XX, 5644, 5675-XX, 5713

**WARNING** - If any Special Control Devices are used with this Fixture, Follow the Instructions Carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a Qualified Electrical Contractor.

**WARNING** - To comply with the National Electric Code and Underwriters Laboratories requirements, the edge of the wall plate coming in contact with the mounting surface, must be sealed with a latex waterproof caulking to prevent water from entering the outlet box.

**WARNING** - For use in unsheltered outdoor areas, this fixture **MUST** be used with accessory Top Cover Lens (Purchased Separately).

**CAUTION** - All glass is fragile, use care when handling lamp(s) or other glass components.



B, C, F, K & M  
(NOT FURNISHED)  
(NO INCLUIDA)  
(NON FOURNIE)

**ASSEMBLY STEPS:**

1. A, C → B
2. D → A
3. E → F
4. G → A
5. H → G, A (USE J)
6. K → L (2X)
7. M → G

TOP COVER ASSEMBLY,  
PURCHASED SEPARATELY.

- 5642-XX: 8798
- 5642-XX30K: 860039
- 5644: 8797
- 5675-XX: 8799
- 5675-XX30K: 860038
- 5713: 8799

