

GENERAL CARE GUIDE FOR HANGING HAMMOCK CHAIRS

Save this guide for future reference.

USE & CARE

- **ROPES:** Even with normal use, all rope-style hammock chairs will stretch. Keep this in mind when hanging this hammock chair.
- **WOODEN SURFACES:** Unfinished surfaces may need to be hand-sanded if stains develop. Take care not to overdo it as it will reduce the strength of the wood. Do not use power tools to sand, it is unsafe and could damage the ropes.
- **SAFE USE:** Do not swing, bounce, jump, twist, or make other excessive movements while using this chair. Misuse of the hammock chair, such as using it like a swing or exceeding the weight limit, can cause the ropes to stretch or break.
- **SUN EXPOSURE:** All fabrics will eventually fade and degrade from sun exposure. The less direct sunlight the hammock chair is exposed to, the longer the life of the ropes will be.
- **CHILDREN:** Supervise children at all times while using this product. Do not allow children or pets to play in the hammock chair. Excessive swinging or rough play may damage the hammock chair and could cause injury.
- **INSPECT:** Before each use, inspect the ropes and spreader bar for wear or weakness.
- **CLEANING:** Clean when soiling or staining is present, and before storage.
- **STORAGE:** Store indoors, in a dry location during inclement weather, winter, and when it will not be used for an extended time. Ensure it is completely dry before storing to prevent mold and mildew growth.

CLEANING



HAND-WASH ONLY



DO NOT USE BLEACH OR FABRIC SOFTENERS



LAY FLAT TO DRY



DO NOT IRON

Spot-clean whenever possible.

Hand-wash in a bathtub or kiddie pool using mild soap or detergent and a soft-bristled scrub brush. Soaking may be required for heavily soiled ropes. Keep the wooden bars and galvanized O-rings out of the water as much as possible.

Rinse away all soap residue and air-dry on a flat surface to prevent the ropes from stretching. The ropes may shrink slightly while drying, but will stretch back out with use.

! SAFETY STATEMENTS & WARNINGS !

- Before each use, inspect your hammock chair for wear or weakness. Do not use if the ropes are frayed or fabric is torn.
- Excessive swinging and other rough play may result in serious injuries.
- Small children should not use the hammock chair unsupervised.
- Pets should not be allowed into hammock chairs as it may result in injury or damage the product.
- Do not exceed the recommended weight capacity of the hammock.
- Never untie the ropes.

Any modification to the product or failure to follow recommended care will void the product warranty.

! WARNING!

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.