


Purchase Date: / Order/Customer Reference Numb
--

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at https://tiny.cc/SunnydazeWarranty If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

SIDEBOARD CABINET WITH DRAWERS AGR-416

Carefully review assembly and care instructions before using this product. Save this document for future reference. **Assemble components on a soft, clean surface to avoid scratching or damaging the finish.**





(!) HELPFUL HINTS

Sunnydaze Decor advises reviewing this manual fully, and assembling the unit soon after purchase. Check that all parts are accounted for and familiarize yourself with the assembly before beginning.

SAVE THIS MANUAL FOR FUTURE REFERENCE.

INTRODUCTION

Read the manual carefully to ensure you fully understand all use, care, assembly, and safety information.



Read this manual carefully and follow the assembly instructions in the order listed. Pay close attention to assembly drawings.



Regularly clean with a clean microfiber cloth to prevent dust accumulation.



Do not paint the unit.

Do not use abrasive materials or cleaners to clean the furniture.



Indoor use only.


Do not expose the furniture to heat or humidity.



When cleaning nearby furniture, do not allow contact with water or cleaners as it may deteriorate the furniture.



Do not allow metal components to come in contact with water or cleaners as it may cause rust and staining.



Assemble on a soft, flat, clean, and dry surface.

Use a soft, protective barrier when assembling the furniture.

TIP: Use the box carton as a protective layer to separate and protect the parts from scratches and other damage during assembly.



Do not push or drag furniture as doing so may damage the unit.

Only move furniture when it is empty.



Always ask for help when moving furniture



Avoid Accidents - Do not climb, sit or stand on the furniture.

Do not allow children to play on or inside the furniture.




Keep sharp objects away as they may scratch or damage the unit.

Do not use the furniture as a writing surface without a padded barrier.


NOTICE:


Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.


COMPONENTS



SEQ.	PART NAME	QTY.	
01	Тор	1	
02	Left Side Panel		
03	Right Side Panel		
04	Bottom Panel		
05	Shelf		
06	Bottom Frame		
07	Center Face Frame		
08	Top Face Frame		
09	Vertical Cabinet Face Frame		
10	Drawer Side (L/R)		
11	Outside Drawer Rail (L/R)		
12	Center Drawer Rail		
13	Center Drawer Rail Support	1	
14	Side Trim Board (L/R)	2	
15	Front Trim Board	1	
16	Backing Board		
17	Divider		
18	18 Left Door		
19	19 Right Door		
20	20 Drawer Face		
21	21 Drawer Bottom		
22	22 Drawer Back		
23	Right Stile		
24	Left Stile		
25	Vertical Drawer Face Frame	1	









This item contains small parts that can be swallowed. Keep children and pets away during assembly.





No.	H	ARDWARE	QTY.
Α		Wood Dowel	44
В		M4.5x28mm Pan Screw	28
С		M3.5x14mm Pan Screw	24
D		M3.5x25mm Pan Screw	10
Е	\bigcirc	Tack	8
F		M4.5x25mm Pan Screw	6
G	So-	Handle Set	4
Н	•	Connector	12
J		Catch	2
K		Strike	2
L		M3.5x30mm Flat Screw	16
М	Silis.	Hinge	4
N	Co	Shelf Pin	4
0	Juliur.	M3x16mm Flat Screw	8
Р	400	■ Drawer Slide	4
Q		M4x8mm Bolt	4
R	anne	M3x14mm Flat Screw	12
Υ		Wall Anchor Kit	1
Z	0	8x8mm Nail	22

ASSEMBLY


Carefully review all steps and fully understand assembly before beginning.


IMPORTANT: Take care not to over-tighten screws as doing so may crack the wood or strip the screw hole, causing a weak connection and reduced stability.








08/2022











WARNING: Check for pipes and electrical wiring before drilling.

IMPORTANT: If walls are not solid like brick, stone or concrete, you will require special fittings (not included). When in doubt, consult a professional.

Carefully measure the location of pilot hole before drilling and installing the unit.

- Place wall mounting strap against the wall and mark the position for drilling the hole.
- Using a power drill with a 6mm bit, drill a hole to 30mm depth. If the wall is softer, using a 5mm bit is recommended.
- Insert the wall anchor into the hole until the opening is flush with the wall.
- Secure the strap to the wall using the 25mm screw and washer.
- Use a 2mm drill bit to pre-drill a small pilot hole on the back of the furniture top. Secure the other end of the strap to the furniture using the 14mm screw and washer.

🚹 SAFETY STATEMENTS & WARNINGS 🗘

- · Residential use only. Not for commercial or industrial use.
- · For indoor use only.
- Ensure fittings are tight before use. Periodically check fitting to ensure they are tight.
- Only use this unit on a flat, level surface.
- · Do not sit, stand or climb on the unit.
- Supervise children; never allow children to climb or sit on this unit as it may tip over and cause serious injury.
- Do not place liquids or hot items directly on the furniture.
- Never use chemical cleaning products or polishes as they may damage the finish.
- · Do not exceed the weight capacity of the furniture.
- Do not overload the drawers as doing so may cause damage.
- · Do not place the unit in direct sunlight.
- Avoid placing unit near heating or cooling vents as forced air is very drying and can damage the unit.
- Do not write on furniture without a padded barrier to protect the surface.

Any modification to the product or failure to follow recommended care will void the product warranty.

If you experience issues with assembly or the product was damaged during shipping, please contact our customer service team directly through one of the methods mentioned at the top of page 1.

Please have the item number and order information ready to expedite response time.



Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

