




Assembly & Installation Instructions

Assembly & Installation Instructions

Copernicus Task Lamp 277830D

C84

Contents



Component Parts

- A. Fixture Base**
- B. LED Assembly**
- C. Stainless Steel Rod (2)**
- D. Gripper (2)**
- E. Power Supply**

Copernicus Task Lamp 277830D

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Please Note: After installation extra hardware and accessories are possible due to our kits are used on multiple products and options.


Complete Lamp Assembly (Figure 1)

1. Carefully unpack the lamp from the carton.
2. Locate (+) and (-) labels on LED assembly (B) with stainless steel rods (C) attached.
3. Follow (+) label along stainless steel rod (C) and align with (+) label on fixture base (A).

Note: LED assembly (B) should be located on same side of fixture base (A) as switch.

4. Insert stainless steel rods (C) into grippers (D).
5. Locate power supply (B). Plug power supply (B) into fixture connector.

Note: Switch is touch sensitive.



If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture. Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.

Castleton, Vermont USA | VERMONTMODERN.COM

37245