

Purchase Date: / / C	Order/Customer Reference Numbe
----------------------	--------------------------------

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at https://tiny.cc/SunnydazeWarranty If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email:


If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

RAISED ADIRONDACK CHAIR

Read all assembly and care instructions carefully before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid scratching or damaging the finish.





No.	Parts		QTY.
A	Sea Sea	at	1
В	Bad	ckrest	1
С	Lef	t Leg	1
D	Rig	ht Leg	1
E	Rig	ht Armrest	1
F	Lef	t Armrest	1
G	Fro	nt Rail	1
Н	← Ba	ck Rail	1
I	& Ba	ck Support	2

No.	HARDWARE		QTY.
1		M6x60mm Bolt Set	12
2		M6x50mm Screw	10
3		M6x80mm Screw	2

INCLUDED TOOLS		
	Hex Key	
	Spanner	

HELPFUL HINT

Do not fully tighten hardware until all components are assembled. If hardware is tightened too soon, mounting holes may not align, and parts may not easily fit together.



CHOKING HAZARD — This item contains small parts that can be swallowed. Keep children and pets away during assembly.

Sunnydaze Decor ••••

SunnydazeDecor.com

ASSEMBLY

Review all steps and understand assembly before beginning.

Do not fully tighten hardware until all components have been loosely assembled.

NOTE: Do not fully tighten hardware until Step 6 is complete.


If hardware is tightened too soon, mounting holes may not align, and parts may not easily fit together.

STEP 1

C: 1 **D**: 1

G: 1

2: 2




Do not fully tighten hardware until Step 6 is complete.

STEP 2

A: 1

H: 1

2: 2




Do not fully tighten hardware until Step 6 is complete.

TIP: Install bolt head on the inside

of the chair, as shown.

STEP 3

1: 6




Do not fully tighten hardware until Step 6 is complete.


STEP 4


E: 1

1: 2



Do not fully tighten hardware until Step 6 is complete.





Care & Maintenance

SAFE USE: For residential use only. Only use on a flat, level surface. Do not stand on the chair. Do not exceed the weight capacity.

INSPECT: Periodically check hardware and tighten as necessary.

CLEAN: Mix a mild soap and water solution and wipe surfaces with a soft, non-abrasive cloth. Rinse with clean water, ensuring all soap residue has been removed. Do not use harsh chemicals or abrasive materials to clean.

WINTER CARE & STORAGE: Protect from inclement weather by moving furniture to an indoor location. Cover while in storage to help prevent dust build-up. When not in use, cover furniture with a breathable cover to help protect it from the effects of sunlight, inclement weather, dust build-up, and collecting debris.

↑ SAFETY STATEMENTS & WARNINGS **↑**

- · Do not exceed the weight capacity.
- · Never stand on the chair.
- Inspect hardware often and tighten loose hardware before use.
- Do not put hot items on or near furniture.
- Keep furniture a safe distance from heat sources such as, but not limited to, fire pits, patio heaters, and grills.
- Do not allow children to use this product without adult supervision.
- Do not use harsh chemicals or abrasive materials to clean the furniture.

Any modification to the product or failure to follow recommended care will void the product warranty.

⚠WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.