

Purchase Date:	/ /	Order/Customer Reference	Number


Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <a href="https://tiny.cc/SunnydazeWarranty">https://tiny.cc/SunnydazeWarranty</a> If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email:


customerservice@sunnydazedecor.com, or via our contact us page at https://tiny.cc/SunnydazeContact

# JULIAN ARMCHAIR GF-284

Read this manual carefully before using this product. Save this manual for future reference.

Assemble components on a soft, clean surface to avoid damaging the finish.





No.	PARTS		
Α	Back Panel	2	
В	Seat	2	
С		2	
D	Eeft Chair Leg	2	
Е	Left Armrest	2	
F	Right Armrest	2	

No.	HARDWARE		QTY.
1		M6x20mm Bolt	20
2		M6x15mm Bolt	4
3	0	M6 Washer	20
4		M4 Hex Key	1

## **⚠** WARNING **⚠**

**CHOKING HAZARD** — This item contains small parts that can be swallowed by children. Keep children away during assembly.




GF-WKD 33 10/2021 Page 1 / 3

#### STEP 1

TIP: remove the wooden seat from the seat frame for easier **A**:1 access when installing the bolts.

**B**:1






Connect Seat (B) to Back Panel (A) using Bolts (1) and Washers (3).

### STEP 2

C:1

**D**: 1






Connect Legs (C, D) to the seat using Bolts (1) and Washers (3).

## STEP 3


E: 1

**F**: 1



Ensure the front of each armrest is aligned with the leg and secure using Bolt (1).

**Tip:** Always fully insert the hex key inside designated notch of the bolt.



If the hex key is not fully inside the notch, the hex key could slip out, causing damage to the bolt head. Repeated hex key slipping will cause the notch to become rounded, making it difficult or impossible to tighten the bolt with the hex key.

Do not use any electronic tools to assemble these product. The high energy of electronic tools will cause hardware to over-tighten, stripping the bolt, bolt head, or bore holes.

Do not over-tighten screws or bolts.

and Washer (3).

Firmly secure each armrest

to the backrest using Bolt (2)

# **Care & Maintenance**

SAFE USE: For residential use only. Only use on a flat, level surface. Do not stand on the chair.

**INSPECT:** Periodically check assembly points and tighten fittings as necessary.

**CLEANING:** Identify the direction of the woodgrain. Following the direction of the woodgrain, wipe surfaces with a soft, dry cloth. Do not use harsh chemicals or abrasive materials or a pressure washer to clean.

**COVER:** When not in use, cover furniture with a breathable cover to help protect it from the effects of sunlight, inclement weather, dust build-up, and collecting debris.

**WINTER CARE & STORAGE:** Protect this item from inclement weather, especially ice and snow. Move to a cool, dry indoor location. Covering while in storage is recommended to help prevent dust build-up.

**WARNING:** THE ONE-YEAR WARRANTY DOES NOT COVER DAMAGES OR DEFECTS CAUSED BY THE USE OF CHEMICAL TREATMENTS OR PROTECTIVE COATINGS.

## 🛕 SAFETY STATEMENTS & WARNINGS 🛕

- Do not exceed the weight capacity of the furniture.
- · Do not stand on the chair.
- Inspect hardware often and tighten loose hardware before use.
- Do not put hot items on or near furniture.
- Do not allow children to use this product without adult supervision.
- Do not use harsh chemicals or abrasive materials to clean the furniture.
- Do not use a pressure washer to clean the furniture.

Any modification to the product or failure to follow recommended care will void the product warranty.



Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.

GF-WKD 33 10/2021 Page 3 / 3