

A482




# Assembly & Installation Instructions

# Assembly & Installation Instructions

Copernicus Double Pendant 139815

A482



139815 Copernicus Double Pendant



Castleton, Vermont USA | VERMONTMODERN.COM

37229

## Component Parts

<b>A</b>	<b>Center Crossbar</b>
<b>B</b>	<b>Outer Crossbar (2)</b>
<b>C</b>	<b>#10 Wood Screw (2)</b>
<b>D</b>	<b>Anchor (2)</b>
<b>E</b>	<b>Gripper (4)</b>
<b>F</b>	<b>Driver</b>
<b>G</b>	<b>Ground Screw</b>
<b>H</b>	<b>Cupped Washer</b>
<b>I</b>	<b>Center Canopy</b>
<b>J</b>	<b>Long Threaded Knobs (2)</b>
<b>K</b>	<b>Outer Canopy (2)</b>
<b>L</b>	<b>Grommets (4)</b>
<b>M</b>	<b>Short Threaded Knobs (4)</b>
<b>N</b>	<b>Small Wooden Ball (4)</b>
<b>O</b>	<b>Stainless Steel Rod (4)</b>
<b>P</b>	<b>LED Assembly (2)</b>
<b>Q</b>	<b>Bent Rod (4)</b>
<b>R</b>	<b>Set Screw (4)</b>

## Copernicus Double Pendant 139815

**CAUTION:** FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Please Note: After installation extra hardware and accessories are possible due to our kits are used on multiple products and options.

### To Install Canopy (Figures 1 & 2 on following page)

**CAUTION: BE SURE POWER IS OFF AT THE MAIN BREAKER BOX PRIOR TO INSTALLATION.**

1. Carefully unpack fixture from carton.
2. Hold crossbar assembly close to the ceiling with mounting holes in center crossbar (A) lined up with junction box. With a pencil, mark the location of the two mounting holes in the outer crossbars (B) on ceiling.
3. Put the crossbar assembly down. If using only the #10 screws (C), drill 1/8" holes in locations marked on ceiling. If using anchors (D) and screws (C), drill 1/4" holes in the locations marked on the ceiling. Place the tapered end of the anchors (D) into the holes and gently tap them flush to the ceiling using a light weight hammer.
4. Thread the wires in the electrical box through the center hole in the center crossbar (A) while moving it into position.
5. Using two machine screws (not provided), fasten the crossbar (A) to the electric box.

Note: A new electric box comes with screws. When replacing a fixture, retain the existing screws for use with the new fixture.

6. Using the #10 screws (C), screw the outer crossbars (B) securely to the ceiling. Be careful not to over-tighten or strip the anchors (D).
7. Using suitable wire connectors (not provided) connect driver (F) wires to supply wires (white to white and black to black). Attach a pigtail lead to the center crossbar (A) using the ground screw (G) and cupped washer (H) found in mounting kit. Connect all ground wires (bare copper or green to bare copper or green) including ground wire found in canopy (I).

**CAUTION: MAKE SURE WIRE CONNECTORS ARE TWISTED ON SECURELY, AND NO BARE WIRE IS EXPOSED.**

8. Slide center canopy (I) over center crossbar (A) and push firmly to ceiling, making sure no wires are pinched between canopy (I) and ceiling. Fasten with long threaded knobs (J)
9. Align grommets (L) with grippers (E). Slide outer canopy (K) over grippers (D) and push firmly to ceiling, making sure no wires are pinched between canopy (K) and ceiling. Fasten with short threaded knobs (M).

Note: Be sure (+) and (-) labels on outer crossbars (B) match the (+) and (-) labels on outer canopies (K) on each side.


Yeah, you got this!



# Assembly & Installation Instructions

Copernicus Double Pendant 139815

A482



(Figure 1)

# Assembly & Installation Instructions

A482

## Copernicus Double Pendant 139815


### To Complete Installation (Figures 3 & 4)

1. Thread the stainless steel rods (O) into the top of the small wooden balls (N).


Note: See Figure 2 for Orientation.

Note: Long Stainless Rods go to Large LED Assembly. Shorter Stainless rods go to Small LED Assembly

2. Locate the (+) and (-) labels on the LED assembly (P).
3. Follow the label along the bent rod (Q) to the small wooden ball (N) with stainless steel rod (O) attached.
4. Insert (+) stainless steel rod (O) into the gripper (E) with the (+) label next to it.
5. Insert (-) rod (O) into remaining gripper (E).
6. Repeat steps 2 thru 5 for remaining led assembly (P).
7. In the bottom of each small wooden ball (N) is a set screw (R). Once desired aesthetic is reached, lock wooden balls (N) in place by tightening the set screws (R) with supplied hex wrench.
8. Restore electricity at main breaker.



(Figure 2)



(Figure 3)



If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture! \* Vermont Modern / Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.

Castleton, Vermont USA | VERMONTMODERN.COM

37229